


Installation Instructions Custom Shower Base Thresholds


Adjustable Threshold – Shower walls and bathroom floor should be installed

1. Carefully measure between the two finished wall panels/tile where the threshold will go
2. Cut threshold to length using a masonry blade in a circular saw
3. Trial fit the threshold over the flange
 - Make sure top of threshold has a slant inward towards shower base so water stays inside.
 - Find the largest gap where the threshold is sitting (either inside or outside of the threshold) and, using a compass, scribe the length of the threshold using the gap as a guideline
4. Cut or grind inside the threshold leg to fit, so the top of the threshold is level left to right
 - With the Adjustable Threshold, you have the ability to move the threshold in or out a couple inches to where it fits best
5. Put a bead of silicone on the bottom of threshold legs and press into place. Let the silicone set.
6. Finish caulking the threshold




Ramp Threshold – Shower walls and bathroom floor should be installed

1. Carefully measure between the two finished wall panels/tile where the ramp goes
 - Note: this end of the shower base should be finished, with no flanges**
2. Cut the ramp to length using a masonry blade in a circular saw
3. Trial fit the ramp up against the shower base. The threshold should be between 1/8" - 1/4" higher than the base where they both meet. If not, you may need to shim up the ramp
4. Using silicone, lay a heavy bead against the front edge of the shower base and enough on the bottom of the ramp to hold it in place. Push the ramp firmly in place, making sure silicone oozes out between the base and ramp to ensure a good moisture safe barrier.
5. Clean off excess silicone and let set.




Installation

Round Drain Slab – Cross Section



Linear Drain Slab Cross-Section



- Bases must be set directly against the studs, level and set in plops of "**Tile Thin-Set Cement**" ** to ensure that there is no movement at all and to provide proper support.
- The shower base is designed to rest directly on the subfloor.
- Strapping can be used if necessary.
- Silicone is recommended for the installation of the drain.
- Do not use plumbers putty as it is an oil base which will discolour/ damaged the product.
- Custom Shower bases come with a threshold, which covers the gab between the floor and the shower base.

Storing the Base

When storing slab bases prior to installation, stand the slab straight up against a wall with the textured side up, or flat on the floor with proper strapping running the length of the edges



Note:

Round Drain (min 12" from stud)
Linear Drain (min 4" from stud)



**Tile Thin-Set Cement can be purchased at your local hardware store.

SEE BACK PAGE FOR THRESHOLD INSTALLATION